

Register your new device on MyBosch now and get free benefits: bosch-home.com/ welcome



Washing machine

WAN282X1GB

[en] User manual and installation instructions



Table of contents

1 S	afety	. 4
1.1	General information	. 4
	Intended use	
1.3	Restriction on user group	. 4
	Safe installation	
	Safe use	. 7
1.6	Safe cleaning and mainten-	
	ance	9
2 P	reventing material damage	10
	nvironmental protection and	
	aving energy	
	Disposing of packaging	
3.2	Save energy and conserve resources	1 1
<i>3 3</i>	Energy saving mode	
0.0	Energy saving mode	
	stallation and connection	
	Unpacking the appliance	
	Contents of package	12
4.3	Requirements for the install-	4.0
1 1	ation location	
	Removing the transit bolts	
	Connecting the appliance	
	Connecting the appliance to	10
4.7	the electricity supply	16
	amiliarising yourself with	47
	our appliance	
	Detergent drawer	
	Control panel	
	·	
	efore using for the first time [•]	19
6.1	Starting an empty washing	
	cycle	19

7 Display	20
8 Buttons	22
9 Programmes	23
10 Accessories	27
11 Laundry 11.1 Preparing the laundry	
12 Detergents and care products	28
13 Basic operation	
13.1 Switching on the appliance13.2 Setting a programme	28
13.3 Adjusting the programme settings13.4 Loading laundry	
13.5 Inserting the measuring aid for liquid detergent	
13.6 Adding detergent and care product13.7 Starting the programme	
13.8 Changing the activated "Ready in" time13.9 Soaking laundry13.10 Adding laundry13.11 Cancelling the pro-	30
gramme 13.12 Resuming the programme	30
when the programme status is Rinse Hold 13.13 Unloading the laundry 13.14 Switching off the appli- ance	30

14 Childproof lock	31
14.1 Activating the childproof lock	31
14.2 Deactivating the childproof lock	31
15 Basic settings	31
16 Cleaning and servicing	31
16.1 Cleaning the drum	
16.2 Cleaning the detergent	52
drawer	32
16.3 Cleaning the drain pump	
17 Troubleshooting	36
17.1 Emergency release	45
18 Transportation, storage and	
disposal	
18.1 Removing the appliance	
18.2 Inserting the transit bolts	
18.3 Using the appliance again	
18.4 Disposing of old appliance	46
19 Customer Service	46
19.1 Product number (E-Nr.) and	
production number (FD)	46
20 Consumption values	48
21 Technical data	49

en

1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For washing machine-washable fabrics and hand-washable wool in accordance with the care label.
- With tap water and commercially available detergents and care products suitable for washing machines.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

▲ WARNING – Risk of electric shock!

Improper installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ► When using a residual current circuit breaker, only use a type with the mtext{mark}.
- Never equip the appliance with an external switching device, e.g. a timer or remote control.
- When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ► Never kink, crush or modify the power cord.

▲ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ► Do not use extension cables or multiple socket strips.
- ► If the power cord is too short, contact Customer Service.
- Only use adapters approved by the manufacturer.

▲ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

► Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer. No other installation method is permitted.
- Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- Do not install a washer-dryer stack on a platform; the appliances may tip over.

▲ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ► Do not let children play with packaging material.

▲ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ► Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level.

If hoses and power cords have been laid incorrectly, this causes a tripping hazard.

Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

► Do not move the appliance by holding onto protruding parts.

▲ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

► Do not touch the sharp edges on the appliance.

Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

▲ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box and turn off the water tap.
- ► Call customer services. → Page 46

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

▲ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

▲ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ► Do not let children play with small parts.

▲ WARNING – Risk of poisoning!

Detergents and care products may result in poisoning if consumed.

- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

▲ WARNING – Risk of explosion!

Laundry that has been pretreated with cleaning agents that contain solvents may cause an explosion in the appliance.

Rinse pretreated laundry thoroughly with water before washing.

▲ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

► Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- Do not sit on or lean against the appliance door.
- ► Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

 Wait for the drum to come to a complete stop before reaching inside.

▲ CAUTION – Risk of scalding!

When you wash at high temperatures, the detergent solution gets hot.

► Do not touch the hot detergent solution.

▲ CAUTION – Risk of chemical burns!

If the detergent drawer is opened, detergent and care products may spray out from the appliance. Contact with eyes or skin may cause irritation.

- Rinse eyes and/or skin thoroughly with clean water if they come into contact with detergents or care products.
- ► If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

▲ WARNING – Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk. An ingress of moisture can cause an electric shock.
- Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

▲ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

Only use the manufacturer's original spare parts and original accessories.

▲ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

► Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

► Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

 Observe the maximum load capacity for each programme and do not exceed it.

 \rightarrow "Programmes", Page 23 The appliance is secured for transportation using transit bolts. Transit bolts which have not been removed may result in material damage and damage to the appliance.

- Before starting up the appliance, remove the transit bolts completely and keep them in a safe place.
- Before transport, fit the transit bolts fully in order to prevent damage in transit.

Material damage may be caused if the water inlet hose is connected incorrectly.

- Tighten the screw connections on the water inlet until they are handtight.
- Ideally, connect the water inlet hose directly to the water tap, without any additional connecting elements such as adapters, extensions, valves or similar.
- Ensure that the inner diameter of the water tap is at least 17 mm.

Make sure that the length of the thread on the connection to the water tap is at least 10 mm.

If the water pressure is too high or too low, the appliance may not be able to operate properly.

- Ensure that the water pressure in the water supply system is at least 100 kPa (1 bar) and max.
 1000 kPa (10 bar).
- If the water pressure exceeds the maximum value specified, a pressure-reducing valve must be installed between the drinking water connection and the hose set of the appliance.
- Do not connect the appliance to the mixer tap of an unpressurised hot-water boiler.

Modified or damaged water hoses may result in material damage and damage to the appliance.

- Never kink, crush, modify or cut through water hoses.
- Only use the water hoses supplied with the appliance or genuine spare hoses.
- Never re-use water hoses that have been used before.

Operating the appliance using water that is dirty or too hot may lead to material damage and damage to the appliance.

 Only operate the appliance with cold mains water.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.

 Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Save energy and conserve resources

If you follow these instructions, your appliance will use less electricity and less water.

Choose programmes with low temperatures and longer wash times and use maximum load capacity.

 Energy consumption and water consumption is most efficient.

detergent based on the laundry's degree of soiling.

For light to normal soiling, a smaller amount of detergent is sufficient. Observe the dosage recommendation from the detergent manufacturer.

Reduce the washing temperature for lightly and normally soiled laundry.

 At lower temperatures, the appliance consumes less energy. For light to normal soiling, lower temperatures than indicated on the care label are also sufficient. Set the maximum spin speed if you want to dry the laundry in the tumble dryer afterwards.

 The drier the laundry, the shorter the programme duration when drying which, in turn, reduces energy consumption. A higher spin speed reduces the residual moisture in the laundry and increases the volume of the spin noise.

Wash the laundry without prewash.

 Washing with prewash increases the programme duration and increases energy and water consumption.

The appliance has a continuous automatic load adjustment function.

 Depending on the type of fabric and load capacity, the continuous automatic load adjustment function optimally adjusts the water consumption and programme duration.

3.3 Energy saving mode

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- 1. Remove any packaging and protective covers completely from the appliance.

→ "Disposing of packaging", Page 11

- 2. Check the appliance for visible damage.
- **3.** Open the appliance door. → "Basic operation", Page 28
- 4. Remove any accessories from the drum.
- 5. Close the appliance door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

 Do not operate the appliance with incomplete or defective accessories. Replace the accessories in question before operating the appliance.

→ "Accessories", Page 27

Note: The appliance has been tested at the factory to check it is in working order. As a result, water stains may remain in the appliance. These marks will disappear after the first wash cycle.

The delivery consists of the following:

- Washing machine
- Accompanying documents
- Transit bolts

 → "Removing the transit bolts", Page 13
- Cover caps
- Water inlet hose
 → "Connecting the water inlet
 hose", Page 14

4.3 Requirements for the installation location

WARNING Risk of electric shock!

The appliance contains live parts. Touching live parts is dangerous.

 Do not operate the appliance without a cover cap.

MARNING Risk of injury!

When using the appliance on a base, the appliance may tip over.

 Always secure the feet of the appliance to a base using the manufacturer's fixing brackets → Page 27 before using the appliance for the first time.

ATTENTION!


If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- Tilt the appliance carefully.
- Transport the appliance in an upright position.

Installation loca- Requirements tion



Installation loca- Requirements tion

Against a wall




Do not trap the hoses between the wall and the appliance.

4.4 Removing the transit bolts


The appliance is secured for transportation using transit bolts on the rear of the appliance.

Note: Keep the transit bolt screws and the sleeves in a safe place for future transport \rightarrow *Page 45*.

1. Pull the hoses out of the holders.




 Unscrew ① and remove ② all screws for the 4 transit bolts with a WAF 13 wrench.




- en Installation and connection
- **3.** Remove the power cable from the **6.** Press down on the 4 cover caps. holder.




4. Remove the 4 sleeves.



5. Put on the 4 cover caps.







4.5 Connecting the appliance

Connecting the water inlet hose

1. Connect the water inlet hose.



2. Connect the water inlet hose to a tap (26.4 mm = 3/4").



3. Open the water tap carefully and check that the connection points are tight.

Water outlet connection types


This information is intended to help you to connect this appliance to the water outlet.

ATTENTION!

When draining, the water outlet hose is subject to water pressure and may come loose from the installed connection point.

 Secure the water outlet hose against unintentional loosening.


Note: Observe the draining heights. The draining heights are: minimum: 60 cm, maximum: 100 cm




4.6 Aligning the appliance

In order to reduce noise and vibration and to prevent the appliance from moving, align the appliance correctly.

 Loosen the lock nuts using a WAF 17 wrench by turning it in a clockwise direction.




2 To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

- en Installation and connection
- **3.** Screw the lock nuts tightly against the housing using a WAF 17 wrench.



In doing so, hold the foot tight and do not adjust its height.

4.7 Connecting the appliance to the electricity supply

Note: Your electrical domestic installation for this appliance must comply with the local legal provisions and safety regulations, and should include a residual current circuitbreaker.

 Insert the mains plug of the appliance's power cable in a socket nearby.


The connection details of the appliance can be found under Technical data \rightarrow Page 49.

2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance


5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Maintenance flap for the drain pump \rightarrow Page 33
2	Door
3	Detergent drawer → Page 18
4	Control panel → Page 18
5	Water outlet hose \rightarrow Page 15
6	Power cord → Page 16
7	Transit bolts → Page 13



5.3 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



Programmes → Page 23	4 Buttons
Programme selector → Page 28	
3 Display → Page 20	


6 Before using for the first time

Prepare the appliance for use.

6.1 Starting an empty washing cycle

Your appliance was inspected thoroughly before leaving the factory. To remove any residual water, run the first wash cycle without any laundry.

- 1. Turn the programme selector to **Cottons 90**°.
- **2.** Close the door.
- 3. Pull out the detergent drawer.
- 4. Pour standard washing powder into compartment II.



To prevent foaming, use only half of the amount of detergent recommended by the detergent manufacturer for light soiling. Do not use detergent suitable for woollens or delicates.

- 5. Push in the detergent drawer.
- 6. Press **Start / Reload** to start the programme.
- The display shows the remaining programme duration.
- After the programme has ended, the display shows: "End".

- 7. Start the first wash cycle or set the programme selector to Off to switch off the appliance.
 → "Pagia operation", Paga 28
 - → "Basic operation", Page 28

7 Display

The display shows the current settings, options or relevant information.

Example: Display

display	Designation	More information
0:40 1	Programme dura- tion/programme time remaining	Approximate expected programme dura- tion or programme time remaining.
10h 1	"Ready in" time	→ "Buttons", Page 22
8,0 kg 1	Recommended load	The maximum load capacity for the selec- ted programme in kg.
1400	Spin speed	Set spin speed in rpm. → "Buttons", Page 22 0= No final spin, only draining : Rinse Hold, no draining
≉ - 90	Temperature	Set temperature in °C. → <i>"Buttons", Page 22</i> * (cold)
-	Start/Pause	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be star- ted or continued.
	Rinse Hold	Programme status
¹ Example		

display	Designation	More information
End	End of pro- gramme	Programme status
س ر)	Childproof lock	 lights up: The childproof lock is activated. flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 31
—	Additional rinse	Additional rinse cycle is activated. → "Buttons", Page 22
—	Prewash	Prewash is activated. → "Buttons", Page 22
_≡Ü	SpeedPerfect	Short wash activated. → "Buttons", Page 22
<u>©</u>	Door	 Lights up: The door is locked and cannot be opened. Flashes: The door is not closed properly. Off: The door is unlocked and can be opened.
ج	Тар	No water pressure.The water pressure is too low.
E:35 / -10 ¹	Error	Error code, error display, signal.
¹ Example		

8 Buttons

The selection of programme settings depends on the programme that is set.

Button	Selection	More information
Start / Reload	StartCancelPause	Start, cancel or pause the pro- gramme.
Speed Perfect	ActivateDeactivate	Activate or deactivate a shorter pro- gramme duration. Note: Energy consumption increases. The washing result is not affected by this.
Finish in	Up to 24 hours	Set the programme end. The programme duration is already in- cluded in the set number of hours. Once the programme has started, the programme duration is displayed.
Temp. °C	卷 - 90 °C	Adjust the temperature in °C.
Spin	1400	Adjust the spin speed or activate – –– (Rinse Hold). If – –– is selected, the water is not drained at the end of the washing cycle and the spin cycle is deactiv- ated. The laundry remains in the rins- ing water.
Cm 3 sec.	ActivateDeactivate	→ "Childproof lock", Page 31
Prewash	ActivateDeactivate	Activate or deactivate prewash, e.g. for washing heavily soiled laundry.
Extra Rinse	ActivateDeactivate	Activate or deactivate an additional rinse cycle. Recommended for particularly sensit- ive skin or in regions with very soft water.

9 Programmes

Note: The laundry's care labels provide you with additional information on programme selection.

Programme	Description	Max. load (kg)
Cottons	 Wash hard-wearing items made from cotton, linen or blended fabrics. Also suitable as a short programme for normally soiled laundry when you activate Speed Perfect. Programme setting: Max. 90 °C Max. 1400 rpm 	8,0 5,0
Eco 40-60	 Wash items made from cotton, linen or blended fabrics. Note: Fabrics which can be washed from 40 °C var up to 60 °C var as per the care symbol can be washed together. The washing performance corresponds to the best possible washing performance class according to the legal requirements. For this programme, the washing temperature is automatically adjusted depending on the load size, in order to achieve the best possible energy efficiency with the best possible washing result. You cannot change the washing temperature. Programme setting: Note: The temperature cannot be adjusted in this programme and is set automatically. Max °C Max. 1400 rpm 	8,0
Cottons Intens- ive	 Wash hard-wearing items made from cotton, linen or blended fabrics. Energy-saving programme. Note: To save energy, the actual washing temperature may deviate from the set washing temperature. The washing performance meets legal requirements. Programme setting: Max. 90 °C Max. 1400 rpm 	8,0

Programme	Description	Max. load (kg)
Easy Care	Wash items made from synthetic or blended fab- rics. Programme setting: Max. 60 °C Max. 1200 rpm	4,0
Mixed Load	 Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for lightly soiled laundry. Programme setting: Max. 60 °C Max. 1400 rpm 	4,0
Night Wash	 Wash items made from cotton, linen, or synthetic or blended fabrics. Suitable for quiet washing at night. The signal at the end of the programme is deactivated and a reduced final spin speed set by default. Programme setting: Max. 60 °C Max. 1400 rpm 	4,0
Delicates / Silk	 Wash delicate, washable items made from silk, viscose and synthetic fabrics. Use a detergent that is suitable for delicates or silk. Note: Wash especially delicate items or items with hooks, eyelets or clips in a mesh laundry bag. Programme setting: Max. 40 °C Max. 800 rpm 	2,0
🗟 Wool	 Hand- or machine-washable items that are made from wool or contain wool. To prevent the laundry from shrinking, the drum moves the items very gently with long pauses. Use a detergent that is suitable for wool. Programme setting: Max. 40 °C Max. 800 rpm 	2,0
Rinse	Rinse and then spin the laundry, and drain the wa- ter. Programme setting: Max. 1400 rpm	_
Spin / Drain	Spin and drain the water. If you only want to drain the water, activate 0. The laundry is not spun. Programme setting: Max. 1400 rpm	_

Programme	Programme Description	
AllergyPlus	 Wash hard-wearing items made from cotton, linen or blended fabrics. Suitable for allergy sufferers and for strict hygiene requirements. Note: Once the set temperature has been reached, it remains constant throughout the entire washing process. Programme setting: Max. 60 °C Max. 1400 rpm 	6,5
Shirts	 Wash non-iron shirts and blouses made from cotton, linen, or synthetic or blended fabrics. Note: Use the Delicates / Silk programme to wash shirts and blouses made from silk or delicate fabrics. Programme setting: Max. 60 °C Max. 800 rpm 	2,0
Sportswear	 Wash sports and leisure items made from synthetic fibres, microfibre or fleece. Use a detergent that is suitable for sports items. Do not use fabric softener. Tip: Use the Easy Care programme to wash heavily soiled laundry. Programme setting: Max. 40 °C Max. 800 rpm 	2,0
Dark Wash	Wash dark-coloured and colour-intense items made from cotton or easy-care fabric, e.g. jeans. Turn laundry inside-out before washing. Use liquid detergent. Programme setting: Max. 40 °C Max. 1200 rpm	4,0
Super Quick 15'/30'	Wash items made from cotton, or synthetic or blen- ded fabrics. Short programme for small items of lightly soiled laundry. The programme duration is approx. 30 minutes. If you wish to reduce the programme duration to 15 minutes, activate Speed Perfect. The maximum load is reduced to 2,0 kg.	4,0

Programme	Description	Max. load (kg)
	Programme setting: Max. 40 °C Max. 1200 rpm	

10 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 46.

	Use	Order number
Water inlet hose exten- sion	Extend the water inlet hose for cold water or AquaStop (approx. 2.50 m).	WMZ2381
Fixing brackets	Improves the stability of the appliance.	WMZ2200
Longer water inlet hose	Replace the standard water inlet hose with a longer hose (2.20 m).	00353925
Elbow	Secure the water outlet hose in place.	00655300
Liquid detergent insert	Measure liquid deter- gent.	00637516
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WMZPW20W

11 Laundry

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

- To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion covers
 - Close all zips, Velcro fasteners, hooks and eyes
 - Tie cloth belts, apron strings, etc. together or use a laundry bag.
 - Tie together longer drawstrings, and tie cords with solid endpieces in hoods or trousers

- Remove curtain hooks and lead strips or use a mesh laundry bag
- Use a mesh laundry bag for small items of laundry, such as children's socks
- Some stubborn or dried-in stains can be removed by washing several times
- Wash large and small items of laundry together
- Do not rub fresh stains but dab them with soapy water
- Separate items of laundry and shake them out, or observe the programme description

12 Detergents and care products

Notes

- You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.
- Observe the information on safety
 → Page 4 and preventing material
 damage → Page 10.

The manufacturer's instructions for use and dosage can be found on the packaging.

Notes

- Only use liquid detergents that are self-flowing
- Do not mix different liquid detergents
- Do not mix detergent and fabric softener
- Do not use products that have expired or are highly congealed
- Do not use products containing solvents, caustic agents or volatile substances (e.g. bleach)

- Use dyes sparingly as salt may damage stainless steel
- Do not use bleaching agents in the appliance

13 Basic operation

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

13.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

→ "Installation and connection", Page 12

• Turn the programme selector to a programme.

13.2 Setting a programme

- Turn the programme selector and set the required programme.
 → "Programmes", Page 23
- 2. If required, adjust the programme settings → Page 28.

13.3 Adjusting the programme settings

Requirement: A programme has been set.

- → "Setting a programme", Page 28
- Adjust the programme settings.
 → "Buttons", Page 22

Note: The programme settings are not saved permanently for the programme.

13.4 Loading laundry

Note: To prevent creasing, take note of the maximum load for the → "Programmes", Page 23.

Requirement: The laundry is prepared.

- → "Laundry", Page 27
- 1. Open the door.

Make sure that the drum is empty.


- 2. Place the laundry in the drum.
- 3. Close the door.

Ensure that there is no laundry trapped in the door.


13.5 Inserting the measuring aid for liquid detergent

If you order the measuring aid as an accessory, you must use the measuring aid.

- **1.** Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.



3. Insert the measuring aid.



4. Insert the detergent drawer.

13.6 Adding detergent and care product

Notes

- Do not use the measuring aid for liquid detergent for gel detergents, washing powder, or if Prewash or "Ready in" time are activated.
- Observe the information about detergents and care products
 → Page 28.
- 1. Pull out the detergent drawer.
- 2. Pour in detergent.
 - → "Detergent drawer", Page 18
- 3. If required, add the care product.
- 4. Push in the detergent drawer.

13.7 Starting the programme

Note: If you want to change the time until the programme ends, set the "Ready in" time first.

- Press Start / Reload.
- The drum rotates and load detection takes place. This can take up to 2 minutes, after which water enters the drum.
- The display shows either the programme duration or the "Ready in" time.
- After the programme has ended, the display shows: "End".

13.8 Changing the activated "Ready in" time

If you have set and activated a "Ready in" time for a delayed programme start, you can change the "Ready in" time again before the programme starts.

Requirements

- The programme is set.
 → "Setting a programme", Page 28
- The "Ready in" time is set and activated.

→ "Buttons", Page 22

1. Press Start / Reload.

The activated "Ready in" time is paused.

- Press Finish in repeatedly until the display indicates the desired "Ready in" time.
- 3. Press Start / Reload.

The changed "Ready in" time is activated.

13.9 Soaking laundry

Note: No additional detergent is required. The washing solution is then used for washing.

- 1. Start the programme.
- To pause the programme, after approx. 10 minutes, press Start / Reload.
- To resume the programme, after the desired soaking time, press Start / Reload.

13.10 Adding laundry

1. Press Start / Reload.

The appliance pauses.

Note: If ^(C) appears, it is not possible to add laundry.

When ^(C) goes out, it is possible to add laundry.

- 2. Open the appliance door.
- 3. Add or remove laundry.
- 4. Close the appliance door.
- 5. Press Start / Reload.

13.11 Cancelling the programme

- 1. Press Start / Reload.
- 2. Open the appliance door.

The appliance door remains locked for safety reasons if the temperature and water levels are high.

- If the temperature is high, start the **Rinse** programme.
- If the water level is high, start the **Spin** programme or select a suitable programme for draining.
 → "Programmes", Page 23
- **3.** Remove the laundry \rightarrow Page 30.

13.12 Resuming the programme when the programme status is Rinse Hold

Requirements

- Rinse Stop is activated.
 → "Buttons", Page 22
- The last rinse cycle of the set programme has ended and the laundry is in the rinsing water.
- Set the **Spin** programme or a programme for draining the water.
 → "Programmes", Page 23
- 2. Press Start / Reload.

13.13 Unloading the laundry

- 1. Open the appliance door.
- 2. Remove the laundry.

13.14 Switching off the appliance

- 1. Turn the programme selector to Off.
- 2. Turn off the tap.
- **3.** Wipe the rubber gasket dry and remove any foreign objects.



4. Leave the appliance door and detergent drawer open so that residual water can evaporate.

14 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

14.1 Activating the childproof lock

- Press and hold the two Cm 3 sec. buttons for approx. 3 seconds.
- The display shows \square .
- The controls are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power failure.

14.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- Press and hold the two C 3 sec. buttons for approx. 3 seconds.
 So that the programme currently running is not cancelled, the programme selector must be set to the initial programme.
- ✓ C goes out in the display.

15 Basic settings

You can configure the basic settings for your appliance to meet your needs.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

16 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.

16.1 Cleaning the drum


CAUTION Risk of injury!

Permanently washing at low temperatures and a lack of ventilation for the appliance may damage the drum and cause injury.


- Regularly run a programme for cleaning the drum or wash at temperatures of at least 60 °C.
- Leave the appliance to dry after every operation with the door open, and leave the detergent drawer to dry.
- Run the Cottons 90° programme without laundry and using all-purpose washing powder.

16.2 Cleaning the detergent drawer


- 1. Pull out the detergent drawer.
- 2. Press down on the insert and remove the detergent drawer.




3. Pull out the insert upwards.



4. Clean the detergent drawer and insert with water and a brush, and then dry them.



5. Fit the insert and click it into place.



6. Clean the opening for the detergent drawer.




7. Push in the detergent drawer.

16.3 Cleaning the drain pump


Clean the drain pump in the event of faults, e.g. blockages or rattling noises.

Emptying the drain pump


- 1. Turn off the water tap.
- 2. Switch off the appliance.
- **3.** Disconnect the appliance's mains plug from the power supply.
- 4. Open and remove the service flap.



5. Slide a sufficiently large container under the opening.




6. Take the drain hose out of the holder.




- 7. A CAUTION Risk of scalding! When you wash at high temperatures, the detergent solution gets hot.
- Do not touch the hot detergent solution.


To allow the detergent solution to flow out into the container, remove the sealing cap.



8. Firmly press on the sealing cap.




9. Insert the drain hose into the holder.




Cleaning the drain pump

Requirement: The drain pump is empty. \rightarrow *Page 33*

- 1. Since water may remain in the drain pump, unscrew the pump cap carefully.
 - The filter insert in the pump housing may become stuck due to coarse particles of dirt. Loosen the dirt and remove the filter insert.




2 Clean the interior, the thread on the pump cap and the pump housing.




The pump cap is comprised of two parts which can be taken apart for cleaning.

- 3. Insert the pump cap.
 - Ensure that the parts of the pump cap are correctly assembled.




4. Screw the pump cap as far as it will go.



The handle on the pump cap must be in a vertical position.

5. Insert and close the service flap.



17 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

Risk of electric shock!

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting
The display goes out and Start / Reload flashes.	Energy-saving mode is activePress any button.The symbol lights up again.
"E:30 / -80"	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.
	Drain pipe or water drain hose is caught or jammed.Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33
	The water outlet hose is connected too high.Install the water outlet hose at a maximum height of 1 metre.
	Pump cover is not correctly assembled.Correctly assemble the pump cover.
	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down).
	 Reduce the amount of detergent for the next washing cycle with the same load.
	Unapproved extension installed on the water drain hose.

Fault	Cause and troubleshooting		
"E:30 / -80"	 Remove any unapproved extensions from the water hose. → "Connecting the appliance", Page 14 		
	 The pump cap is not fully screwed in. Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position. 		
"E:36 / -25 / -26"	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33		
"E:60 / -2B"	 The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Redistribute the laundry in the drum. 		
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.		
"E:30 / -10" and/or	The water pressure is low. No remedial action possible.		
	The filters in the water inflow are blocked.Clean the filters in the water inflow.		
	The tap is turned off. • Turn on the tap.		
	 The water inlet hose is kinked or jammed. Ensure that the water inlet hose is not kinked or jammed. 		
	Water level measurement system is defective.		
	Note: With the error message, the appliance starts a draining process.		
	1. First wait approx. 5 minutes until the drain process ends.		
	2. To reset the error message, switch the appliance off.		
	3. Switch the appliance back on.		
	 4. If the error message is displayed again, call customer service. → "Customer Service", Page 46 		
© lights up.	The temperature is too high.		
	Wait until the temperature has dropped.		
	► → "Cancelling the programme", Page 30		
	Water level is too high.		

Fault	Cause and troubleshooting
© lights up.	 Select a suitable programme for draining. → "Programmes", Page 23
© flashes.	Door is not closed. 1. Close the door. 2. Press Start / Reload to start the programme.
	 Laundry is caught in the door. Open the door again. Remove any trapped laundry. Close the door. Press Start / Reload to start the programme.
All other error codes.	Malfunction Call the after-sales service. → "Customer Service", Page 46
"E:30/-20"	 Solenoid valve defective. ► Call the after-sales service. → "Customer Service", Page 46
	 Detergent dosage is too high. Reduce the amount of detergent for the next washing cycle with the same load.
	Additional water is added.Do not add any extra water to the appliance while it is operating.
The appliance is not working.	The mains plug of the power cord is not plugged in.Connect the appliance to the power supply.
	The circuit breaker in the fuse box has tripped.Check the circuit breaker in the fuse box.
	There has been a power cut.Check whether the lighting in your kitchen or other appliances are working.
The programme does not start.	You have not pressed Start / Reload. ► Press Start / Reload.
	Door is not closed. 1. Close the door. 2. Press Start / Reload to start the programme.
	Childproof lock is activated. ► → "Deactivating the childproof lock", Page 31
	 Finish in is activated. Check whether Finish in is activated. → "Buttons", Page 22

Fault	Cause and troubleshooting
The programme does not start.	 Laundry is caught in the door. Open the door again. Remove any trapped laundry. Close the door. Press Start / Reload to start the programme.
The door cannot be opened.	 is activated. Continue the programme by selecting Spin or Drain and pressing Start / Reload. → "Resuming the programme when the programme status is Rinse Hold", Page 30
	 The temperature is too high. ▶ Wait until the temperature has dropped. ▶ → "Cancelling the programme", Page 30
	 Water level is too high. Select a suitable programme for draining. → "Programmes", Page 23
	 Power failure. Open the door using the emergency release. → "Emergency release", Page 45
The water is not drain- ing.	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.
	Drain pump is blocked. ► → "Cleaning the drain pump", Page 33
	 is activated. Continue the programme by selecting Spin or Drain and pressing Start / Reload. → "Resuming the programme when the programme status is Rinse Hold", Page 30
	 The water outlet hose is connected too high. Install the water outlet hose at a maximum height of 1 metre.
	Pump cover is not correctly assembled.Correctly assemble the pump cover.
	Detergent dosage is too high.

<u> </u>	
Fault	Cause and troubleshooting
The water is not drain- ing.	 Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load.
	 Unapproved extension installed on the water drain hose. Remove any unapproved extensions from the water hose.
	→ "Connecting the appliance", Page 14
	 The pump cap is not fully screwed in. Ensure that the pump cap is screwed in all the way into the appliance. The handle on the pump cap must be in a vertical position.
Water is not flowing in. Detergent is not being dispensed.	You have not pressed Start / Reload. Press Start / Reload.
	The filters in the water inflow are blocked.Clean the filters in the water inflow.
	The tap is turned off. ► Turn on the tap.
	The water inlet hose is kinked or jammed.Ensure that the water inlet hose is not kinked or jammed.
The spin cycle runs several times.	The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
The programme dura- tion changes during the wash cycle.	The programme operation is optimised electronically.This may change the programme duration.Not a fault – no action required.
	 The unbalanced load detection system eliminates an imbalance by repeatedly redistributing the laundry. Not a fault – no action required.
	Note: When loading, where possible, place large and small items of laundry together in the drum. Different sized items of laundry distribute themselves better during the spin cycle.

Fault	Cause and troubleshooting	
The programme dura- tion changes during the wash cycle.	Foam detection system switches on a rinse cycle if foam build-up is too high.Not a fault – no action required.	
No water is visible in the drum.	 Water is below the visible area. Not a fault – no action required. Do not add any extra water to the appliance while it is operating. 	
Drum jerks after the programme starts.	This is caused by an internal motor test.Not a fault – no action required.	
Residual water is present in the compartment &.	Insert in compartment [®] is blocked. ► → "Cleaning the detergent drawer", Page 32	
Vibrations and move- ment of the appliance	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 15	
whilst spinning.	 The appliance feet are not fixed. Secure the appliance feet. → "Aligning the appliance", Page 15 	
	Transit bolts have not been removed. ► → "Removing the transit bolts", Page 13.	
Drum rotates, water does not flow in.	Load detection is active.Not a fault – no action required.	
	Note: The load detection can take up to two minutes.	
Heavy foam build-up	 Detergent dosage is too high. Immediate measure: Mix one tablespoon of fabric softener with 0.5 litres of water and pour the mixture into the left-hand compartment (not for outdoor clothing, sportswear or items stuffed with down). Reduce the amount of detergent for the next washing cycle with the same load. 	
High spin speed not reached.	A low spin speed is selected.The next time you run a wash cycle, set a higher spin speed.	
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.Redistribute the laundry in the drum.	
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.	
	 Start the Spin programme. 	

Fault	Cause and troubleshooting
The spin programme does not start.	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.
	The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distrib- uted.
	 Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	 Start the Spin programme.
Rushing, hissing noise.	Water is flushed under pressure into the detergent drawer. ► Not a fault – normal operating noise.
Loud noises during the spin cycle.	Appliance is not correctly aligned. ightarrow "Aligning the appliance", Page 15
	 The appliance feet are not fixed. ▶ Secure the appliance feet. → "Aligning the appliance", Page 15
	Transit bolts have not been removed. → "Removing the transit bolts", Page 13.
Banging noises, rat- tling in the drain pump.	Foreign bodies have got into the drain pump. ► → "Cleaning the drain pump", Page 33
Slurping, rhythmical suction noise.	The drain pump is active, the detergent solution is pumped out. ► Not a fault – normal operating noise.
Creasing.	 The spin speed is too high. ► The next time you run a wash cycle, set a lower spin speed.
	 The load is too large. ► The next time you run a wash cycle, reduce the amount of laundry being loaded.
	Unsuitable programme for the type of fabric.Select the programmes that are suitable for the type of fabric.

E It	O
Fault	Cause and troubleshooting
Detergent or fabric softener drips off the seal and collects on the door or in the seal fold.	 Too much detergent/fabric softener in the detergent drawer. When dosing liquid detergent and fabric softener, observe the marking in the detergent drawer and do not dose above this.
The spin result is not satisfactory. The laun- dry is too wet/too damp.	 A low spin speed is selected. The next time you run a wash cycle, set a higher spin speed. Start the Spin programme.
	Drain pipe or water outlet hose is blocked.Clean the drain pipe and the water outlet hose.
	 Drain pipe or water drain hose is caught or jammed. Ensure that the drain pipe and water drain hose are not kinked or trapped.
	 The unbalanced load detection system has interrupted the spin cycle because the laundry is unevenly distributed. Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	 Start the Spin programme.
	Unbalance load detection system is using a reduced spin speed to eliminate an unbalance.Redistribute the laundry in the drum.
	Note: Where possible, mix large and small items in the drum. Different sized items of laundry distribute themselves better during the spin cycle.
	 Start the Spin programme.
Detergent residue on the damp washing.	Detergents may contain water-insoluble substances that deposit on the laundry.Start the Rinse programme.
Detergent residue on the dry laundry.	Detergents may contain water-insoluble substances that deposit on the laundry.Brush out the laundry after washing and drying.
Water is leaking out at the water inlet hose.	 Water inlet hose is not correctly/securely connected. 1. Connect the water supply hose correctly. → "Connecting the water inlet hose", Page 14 2. Tighten the screw connection.

Fault	Cause and troubleshooting
Water is leaking out at the water outlet hose.	The water outlet hose is damaged.Replace the damaged water outlet hose.
	 Water outlet hose is not connected correctly. Connect the water outlet hose correctly. → "Water outlet connection types", Page 15
Odours have formed in the appliance.	 Humidity and detergent residue may promote the formation of bacteria. → "Cleaning the drum", Page 32 If you are not using the appliance, leave the door and detergent drawer open so that residual water can evaporate.

Transportation, storage and disposal en


17.1 Emergency release

Releasing the door

Requirement: The drain pump is empty. → *Page 33*

- 1. **ATTENTION!** Escaping water may cause material damage.
- Do not open the door if you can see water through the glass.

Pull the emergency release downwards with a tool and release.



- ✓ The door lock is released.
- 2. Insert the maintenance flap and lock it into place.
- 3. Close the maintenance flap.

18 Transportation, storage and disposal

You can find out here how to prepare your appliance for transportation and storage. You will also find out how to dispose of old appliances.

18.1 Removing the appliance

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on www.boschhome.com.


- 1. Turn off the tap.
- 2. Empty the water inlet hose.

- 3. Switch off the appliance.
- 4. Unplug the appliance's mains plug.
- Drain the water.
 → "Cleaning the drain pump", Page 33
- 6. Detach the hoses.

18.2 Inserting the transit bolts

Secure the appliance for transportation using transit bolts in order to prevent damage.

1. Use a screwdriver to remove the 4 cover caps.



Keep the cover caps.

2 Install the 4 transit bolts. Refer to the description

→ "Removing the transit bolts", Page 13 for this and proceed in reverse order.

18.3 Using the appliance again

For further information, see
 → "Installation and connection",
 Page 12 and
 → "Before using for the first time",
 Page 19.

18.4 Disposing of old appliance

Valuable raw materials can be reused by recycling.

WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.

This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

19 Customer Service

If you have any queries on use, are unable to rectify faults on the appliance yourself or if your appliance needs to be repaired, contact Customer Service.

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

19.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

20 Consumption values

The following information is provided in accordance with the EU Ecodesign Regulation. The values given for programs other than the **Eco 40-60** are indicative only and were determined in accordance with the applicable standard EN60456.

Programme	Load (kg)	Pro- gramm e dura- tion (h:min) ¹	Energy con- sump- tion (kWh/ cycle) ¹	Water con- sump- tion (I/ cycle) ¹	Max- imum temper- ature (°C) 5 mins ¹	Spin speed (rpm) ¹	Resid- ual mois- ture (%) ¹
Eco 40-60 ²	8,0	3:35	1,048	65,0	45	1400	50,00
Eco 40-60 ²	4,0	2:43	0,561	45,0	36	1400	52,00
Eco 40-60 ²	2,0	2:33	0,223	33,0	24	1400	58,00
Cot- tons 20 °C	8,0	3:14	0,350	85,0	23	1400	53,00
Cot- tons 40 °C	8,0	3:14	1,170	85,0	44	1400	53,00
Cot- tons 60 °C	8,0	3:14	1,440	85,0	56	1400	53,00
Cot- tons 40 °C + Prewash	8,0	3:44	1,200	85,0	44	1400	53,00
Easy Care 40 °C	4,0	2:29	0,770	63,0	43	1200	30,00
Mixed Load 40 °C	4,0	1:00	0,620	44,0	41	1400	55,00
ت Wool 30 °C	2,0	0:41	0,220	40,0	22	800	25,00

¹ Due to the influence of water pressure, hardness and inlet temperature, ambient temperature, type, amount and soiling of laundry, detergent used, fluctuations in the power supply and the selected additional functions, the actual values may deviate from the stated values.

² Test programme in accordance with the EU Ecodesign Directive and the EU Energy Labelling Regulation with cold water (15 °C).

21 Technical data

Appliance height	84,8 cm
Appliance width	59,8 cm
Appliance depth	55,0 cm
Appliance depth with door closed	60,0 cm
Appliance depth with door open	101.7 cm
Weight	68,9 kg1
Maximum load	8,0 kg
Mains voltage	220-240 V, 50 Hz
Minimum in- stallation protec- tion	10A
Nominal power	2300 W
Power consump- tion	 Off mode: 0,12 W Left-on mode: 0,50 W
Water pressure	 Minimum: 100 kPa (1 bar) Maximum: 1000 kPa (10 bar)
Length of the wa- ter inlet hose	150 cm
Length of the wa- ter outlet hose	150 cm
Length of the power cord	210 cm
¹ Depending on th cifications	ne appliance spe-
You can find more your model online https://eprel.ec.eur address is linked to	at opa.eu/1. This web

EPREL product database. Please then follow the instructions on searching for the model. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

Technical data en

¹ Only applies to countries in the European Economic Area



Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- Expert tips & tricks for your appliance
- Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**

BOSCH HOME APPLIANCES SERVICE

Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company



Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom